



Aiko Design Ltd. Tel: 0191 296 4295 www.aiko-design.co.uk

All sets for-

Vauxhall Vivaro 2014 onwards

Thank you for choosing **Aiko Design** roof bars – we aim to produce a no-nonsense product so all you will need to install your bars are some 10 and 13mm spanners and a means to safely work at a comfortable height above your van without falling off (this would not only void your personal warranty, but it would make your mates laugh, too)

Here (*right*) are two of your brackets, shown as if you are viewing the left hand/near side of your vehicle. The narrower bracket goes at the front and the rest are all the same- they only need the ‘**AIKO**’ stickers facing outwards to be correctly positioned. (Plus, passers-by will be able to see where you got such fabulous roof bars)



Attach the brackets with the M6 bolts and spring washers provided; there's no need to over-tighten anything- once the spring washers are flat and the bracket is secure, you're good to go.

Next you can add your cross bars; these simply lay across the tops of your brackets, securing with the A-bolts, washers and M8 Nyloc nuts supplied.

Make sure that everything is secure and don't forget to give your rack periodic spanner-checks over the next week or so just in case it needs any settling down on the roof and that's it; we suggest a nice cup of tea at this stage, and perhaps a biscuit.

Hopefully you've had no bother but should you get stuck with anything please give us a call and we'll be happy to talk you through it.

Cheers!

Note- Please check your vehicle manufacturer's handbook for the maximum recommended roof load